




This product contains a light source in energy efficiency class G /
Dette produkt indeholder en lyskilde i energieffektivitetsklasse G

1. Put power cable (D) into the ceiling fix plate (C) and connect main power 220~240V.
2. Fix screws (B) into ceiling.
3. Put screws (A) into the holes on the ceiling fix plate (C), then fix screws (H) on the ceiling fix plate.
4. Put canopy box (E) to fit screws (A) and lock the canopy box with screws (F).
5. Adjust the hanging length (G).

-
1. Sæt strømkablet (D) i monteringspladen (C) og tilslut hovedstrømmen 220~240V.
 2. Fastgør skruerne (B) i loftet.
 3. Sæt skruerne (A) i hullerne på monteringspladen (C), og fastgør derefter skruerne (H) på monteringspladen.
 4. Placer baldakinboksen (E) så den passer til skruerne (A), og lås baldakinboksen med skruerne (F).
 5. Ophængslængde justeres (G).